

ONE STOP SHOPPING FOR METAL CASTERS

1382 Lear Industrial Park Avon, OH 44011 (440) 937-7979 FAX (440) 937-7999 www.dykast.com sales@dykast.com

SUPER LADLE INFORMATION SHEET

SUPER LADLE INFORMATION, CARE AND MAINTENANCE

- The ladles are made out of expanded steel, a ceramic fiber, Refractory saturated fiberglass, Refractory cement, and Boron Nitrite.
- Ladles should be stored in a dry environment. Prior to leaving our facility they are heated to 500°f for 2 hours.
- They should be preheated prior to use as they can pick up moisture in transit especially in the winter.
- Repair kits and Boron Nitrite Lubricoat (blue coating) are available from Dy-Kast Supply and Equipment.

SUPER LADLE REPAIR KIT INSTRUCTIONS

- 1. Remove all aluminum.
- 2. Pack the wet felt in the damaged area using the paint as an adhesive.
- 3. Place a piece of fiberglass tape over the wet felt again using the paint as an adhesive.
- 4. Dry thoroughly.
- 5. Sand smooth using fine grit sand paper.
- 6. Coat area with paint. (2 coats)
- 7. Make sure there is no moisture prior to using again.

WE ACCEPT ALL MAJOR CREDIT CARDS